

V2 Magnet Mount Test



Scan the QR Code on the right to find video instructions online or go to www.sewverlander.com/fitment/

You will need: V2 Magnet Mount Test, painter's tape (optional), and Phillips head screwdriver.

NOTE: The Magnet Mount Test is for testing fitment only and does not contain magnets.

Step 1. Unlock and open your camper's passenger side panel.

Step 2. Locate the lock closest to the cab of your truck. Lift the panel slightly and place the lock in the locked position, then gently lower the panel to rest in the down position.

Step 3. Place a piece of tape over the lock to hold it in position. Also place a piece of tape on one side of the Magnet Mount Test.

Step 4. Lift the panel to access the rear of the lock.

Step 5. Remove the bracket holding the lock in place by unscrewing the middle screw.

Step 6. Place Magnet Mount Test over the lock. Re-install the bracket over the Magnet Mount Test and remove the tape.

Step 7. Carefully lower the panel a little. Before lowering it too far, unlatch to open the lock. Now lower the panel to the closed position.

Step 8. Gently close the locking latch as you normally would. If it closes and locks without any interference, the Magnet Mount Test is a success.

If the locking latch is unable to close and lock, this indicates the Magnet Mount interferes with the lock and will not work with your camper.

Remove the test mount when you are done.

Scan the QR code below or visit www.sewverlander.com/findings to report your findings.



Passenger Side

Front Right Magnet Mount Test

